

DRIVER SAFETY TIPS

Following these tips can help drivers and fleets avoid the potentially serious costs and consequences associated with collisions.


- **Safe, conscientious driving is the best way to reduce risk.** Always drive safely. It's up to the driver to exercise good judgment, maintain vehicle control, and take measures to avoid an accident. The Lytx® event recorder can help drivers evaluate if they performed these actions effectively, and where there's opportunity to improve. However, as a driver aid only, it cannot compensate for a driver who is distracted, inattentive, or impaired by fatigue, drugs, or alcohol.
- **Seat belts are designed to help save lives.** Be sure to always wear a properly fastened seat belt while operating or riding as a passenger in a vehicle.
- **Laws and regulations are in place for good reasons.** Always follow the law to help protect yourself and others on the road.

Certain conditions may limit the event recorder's functionality, resulting in false, few, or no warnings.

These include:

- Weather
- Construction zones
- Dirt, curvy, or winding roads
- Heavy or complicated traffic
- Lens obstruction

If your DriveCam Event Recorder is not functioning properly at any time, contact your supervisor and have the device inspected immediately so that the issue can be corrected.




DRIVER GUIDE

Lytx DriveCam® Event Recorders

Lytix® fleet solutions can help protect you and your organization from false claims. It uses an event recorder to capture video that can help prove when you've done everything right.

EVENT RECORDER WALKAROUND

- 1 Serial number (on side of device)
- 2 Microphone
- 3 Status lights
- 4 Manual record buttons
- 5 Lens



STATUS LIGHTS

GREEN LIGHTS, BACK AND FORTH

Device is booting.



SOLID GREEN LIGHT

Device is on and ready for use.



RED LIGHTS, BACK AND FORTH

Device is recording an event.



SOLID YELLOW LIGHT

Error. Notify your manager.





HOW TO TAG AN EVENT

To record or tag a video event on demand, press one of the blue buttons on the bottom of the event recorder as quickly as possible, and only when it is safe to do so.

The event recorder will save at least eight seconds of video before the button was pushed, and will include your GPS location and speed.

This feature comes in handy if:


- You're involved in a collision, but there wasn't enough force to activate the event recorder.
- You need to document a safety concern, such as a drunk driver.
- You're in a near-collision that doesn't activate the event recorder, but requires review.
- You're going to miss your delivery time for reasons beyond your control (such as a locked gate).
- You witness a third-party collision.



A progression of flashing green lights indicates that the event is being saved.

HOW TO SEND EVENTS IMMEDIATELY

- Press and hold one of the blue buttons. The center LED light will start out green, disappear, and then re-appear green. Let go when it re-appears.
- If the check-in is successful, all LED status lights will light up one-by-one from left to right, each light going from blinking to solid green.
- If the check-in is unsuccessful, one of the first 3 lights will light up red.



Notify your supervisor if you have performed this action.